

FOGMAKER



I N T E R N A T I O N A L A B

EN



PARTS CATALOGUE

Fogmaker parts and merchandise



Content

How to...	IV
Piston accumulators, Ø151 single	1
Piston accumulators, Ø151 double	4
Piston accumulators, Ø151 triple	6
Piston accumulators, Ø178 single	7
Brackets & Clamps	8
Novec™ Extinguishers	9
Revision kits	9
Protection boxes	10
Distribution system	11
Nozzles	11
Distribution hoses	12
Pipes & fittings	16
Detection system	21
Detector bottles	21
Detector tube	22
Couplings	23
Installation material	24
Alarm units	26
Handles & Actuators/Punches	28
Tools	30
Chemicals	32
Technical documentation	33
Labels & Signs/Plates	37
Merchandise	41
INDEX	42

How to understand part numbers for piston accumulators:

Single cylinders:

Part numbers for single suppression cylinders starts with 10XX or 11XX.

The third number indicates the volume: 3=3.3L, 4=4.0L, 6=6/6.5L, 7=7.5L, "12"=11.5L.

Fourth number indicates type of activation:

- 0=mechanical wire,
- 1=electrical,
- 2=hydro pneumatic detector tube.

The following extensions on the part number can occur:

- AIR=No gas or fluid, meant for air freight
- MS=Equipped with micro switch for the safety screw
- T=T-connection for detector tube
- 0=-5°C extinguishant
- 0AS=0°C extinguishant for the Australian market
- 01=With detector bottle
- 02=Pressure switch, AMP-plug
- 020=Release valve, Version 2
- 030=Signal module
- 05=Without manometer
- 90=90° angle for the manometer

Double cylinders:

Part numbers for double suppression cylinders starts with **12XX**, the volume of extinguishant is double the indicated number in the third number, otherwise same as for single suppression part numbers.

Triple cylinders:

Part numbers for triple suppression cylinders starts with **12X3X**, the volume of extinguishant is triple the indicated number in the third number, the fifth number indicates type of activation otherwise same as for single suppression part numbers.

UL-certified systems

Items marked with ^{UL} are used in UL-certified systems.

BE ADVISED

Unless otherwise indicated the extinguishant in all piston accumulators is freeze protected down to -35°C



Piston accumulators, Ø151 single

Piston accumulators, 3.3L

Description	Part number
	Extinguisher 3.3L Mechanical actuation
	Extinguisher 3.3L E (Not for trains)
	Extinguisher 3.3L H.P.actuation 0°C
	Extinguisher 3.3L H.P.actuation
	Extinguisher 3.3L H.P.actuation 0°C Pressure switch
	Extinguisher 3.3L H.P.actuation Pressure switch
	Empty Extinguisher 3.3L H.P.actuation Pressure switch for Air freight
	Extinguisher 3.3L HP/PS/Sig. mod.
	Extinguisher 3.3L H.P.actuation 0°C Pressure switch Australian market

Average filled weight: 11 kg, Height: 440 mm, Depth w bracket ~ 176mm

Piston accumulators, 4L

Description	Part number
	Extinguisher 4L Mechanical actuation 0°C
	Extinguisher 4L Mechanical actuation
	Extinguisher 4L M/PS
	Extinguisher 4L M/PS/Sig. mod.
	Empty Extinguisher 4L Mechanical actuation
	Extinguisher 4L H.P.actuation
	Extinguisher 4L H.P.actuation 0°C Pressure switch
	Extinguisher 4L H.P.actuation Pressure switch
	Empty Extinguisher 4L H.P.actuation Pressure switch for Air freight
	Extinguisher 4L HP/PS/Sig. mod.
	Empty Extinguisher 4L HP/PS/Sig. mod.
	Extinguisher 4L H.P.actuation UL-Listed
	Empty Extinguisher 4L H.P.actuation Air freight
	Extinguisher 4L H.P.actuation 0°C Pressure switch Australian market

Average filled weight: 12.5 kg, Height: 485 mm, Depth w bracket ~ 176mm

Piston accumulators, 6.5L

Description		Part number
	Extinguisher 6.5L Mechanical actuation	1060-020
	Empty Extinguisher 6.5L Mechanical actuation for Air freight	1060-020-AIR
	Extinguisher 6.5L H.P.actuation 0°C	1062-0-020
	Extinguisher 6.5L HP kit incl. 24 bar detection bottle not assembled	1062-01-020
	Extinguisher 6.5L H.P.actuation	1062-020
	Extinguisher 6.5L H.P. 0°C, PS	1062-02-0-020
	Extinguisher 6.5L H.P.actuation Pressure switch	1062-02-020
	Empty Extinguisher 6.5L H.P.actuation Pressure switch for Air freight	1062-02-020-AIR
	Extinguisher 6.5L HP/PS/Sig. mod.	1062-02-030
	Empty Extinguisher 6.5L H.P.actuation for Air freight	1062-020-AIR
	Extinguisher 6.5L H.P.actuation 0°C Pressure switch Australian market	1062-02-0AS-020
	Extinguisher 6.5L H.P.actuation 0°C Pressure switch T-connector	1062-02-0-T-020
	Extinguisher 6.5L H.P.actuation Pressure switch Angled gauge	1062-02-90-020
	Extinguisher 6.5L H.P.actuation UL-Listed	1062-02-08-030 ^{UL}
	Extinguisher 6.5L H.P.actuation Angled gauge	1062-90-020
	Empty Extinguisher 6.5L H.P.actuation Angled gauge	1062-90-020-AIR

Average filled weight: 17.5 kg, Height: 740 mm. Depth w bracket ~ 176mm

Piston accumulators, 7.5L

Description		Part number
	Extinguisher 7.5L Manual actuation	1070-020
	Empty Extinguisher 7.5L Manual actuation Pressure switch	1070-02-020-AIR
	Extinguisher 7.5L M/PS/Sig. mod.	1070-02-030
	Empty Extinguisher 7.5L Manual actuation	1070-020-AIR
	Extinguisher 7.5L E/PS (Not for trains)	1071-02-020
	Extinguisher 7.5L H.P.actuation 0°C	1072-0-020
	Extinguisher 7.5L H.P.actuation	1072-020
	Extinguisher 7.5L H.P.actuation 0°C Pressure switch	1072-02-0-020
	Extinguisher 7.5L HP/PS/Sig. mod. 0°C	1072-02-0-030
	Extinguisher 7.5L H.P.actuation Pressure switch	1072-02-020
	Empty Extinguisher 7.5L H.P.actuation Pressure switch for Air freight	1072-02-020-AIR
	Extinguisher 7.5L HP/PS/Sig. mod.	1072-02-030
	Empty Extinguisher 7.5L HP/PS/Sig. mod.	1072-02-030-AIR
	Extinguisher 7.5L H.P.actuation UL-Listed	1072-02-08-030 ^{UL}
	Empty Extinguisher 7.5L H.P.actuation for Air freight	1072-020-AIR
	Extinguisher 7.5L H.P.actuation 0°C Pressure switch Australian market	1072-02-0AS-020
	Extinguisher 7.5L H.P.actuation with detect. bottle	1072-03-020
	Empty Extinguisher 7.5L H.P.actuation w/ EMPTY detect. bottle AIR	1072-03-020-AIR

Average filled weight: 20 kg, Height: 805 mm. Depth w bracket ~ 176mm

Piston accumulators, Ø151 double

Piston accumulators, 6.6L

Description	Part number
	Extinguisher 6.6L H.P.actuation
	Extinguisher 6.6L H.P.actuation
	Extinguisher 6.6L H.P.actuation with pressure switch and detect. bottle

Average filled weight: 23 kg, Height: 440 mm, Width: 380 mm, Depth w bracket ~ 176mm

Piston accumulators, 8L

Description	Part number
	Extinguisher 8L Mechanical actuation
	Extinguisher 8L Mechanical actuation Pressure switch
	Extinguisher 8L E (Not for trains)
	Extinguisher 8L H.P.actuation detector cylinder mount. on extinguisher
	Extinguisher 8L H.P.actuation
	Extinguisher 8L H.P.actuation Pressure switch
	Empty Extinguisher 8 H.P.actuation Pressure switch for Air freight
	Extinguisher 8L HP/PS/Sig. mod.

Average filled weight: 24.5 kg, Height: 485 mm, Width: 380 mm, Depth w bracket ~ 176mm

Piston accumulators, 13L

Description	Part number
	Extinguisher 13L Mechanical actuation Pressure switch
	Empty Extinguisher 13L Mechanical actuation Pressure switch for Air freight
	Empty Extinguisher 13L Mechanical actuation Air freight
	Extinguisher 13L E (Not for trains)
	Extinguisher 13L E/PS (Not for trains)
	Empty Extinguisher 13L E/PS Metron (Not for trains)

Average filled weight: 36 kg, Height: 740 mm, Width: 380 mm, Depth w bracket ~ 176mm

Piston accumulators, 13L, cont.

Description		Part number
	Empty Extinguisher 13L E/TV/Sig. mod. Metron (Not for trains)	1261-02-030-AIR
	Extinguisher 13L H.P.actuation	1262-020
	Extinguisher 13L H.P.actuation 0°C Pressure switch	1262-02-0-020
	Extinguisher 13L HP Pressure switch	1262-02-020
	Empty Extinguisher 13L H.P.actuation Pressure switch for Air freight	1262-02-020-AIR
	Extinguisher 13L HP/PS/Sig. mod.	1262-02-030
	Extinguisher 13L H.P.actuation Pressure switch Detector cylinder mount. on extinguisher	1262-02-03-020
	Empty Extinguisher 13L H.P.actuation for Air freight	1262-020-AIR
	Extinguisher 13L H.P.actuation 0°C Pressure switch Australian market	1262-02-0AS-020
	Extinguisher 13L H.P.actuation kit detector cylinder mount. on extinguisher	1262-03-020
	Extinguisher 13L HP/PS/Sig. mod. with detector bottle	1262-03-030

Average filled weight: 36 kg, Height: 740 mm, Width: 380 mm, Depth w bracket ~ 176mm

Piston accumulators, 15L

Description		Part number
	Extinguisher 15L Mechanical actuation Pressure switch	1270-02-020
	Extinguisher 15L E (Not for trains)	1271-020
	Extinguisher 15L E/PS (Not for trains)	1271-02-020
	Empty Extinguisher 15L E/PS/Sig. mod. Metron (Not for trains)	1271-02-030-AIR
	Extinguisher 15L H.P	1272-020
	Extinguisher 15L H.P.actuation 0°C Pressure switch	1272-02-0-020
	Extinguisher 15L H.P.actuation Pressure switch	1272-02-020
	Empty Extinguisher 15L H.P.actuation Pressure switch for Air freight	1272-02-020-AIR
	Extinguisher 15L HP/PS/Sig. mod.	1272-02-030
	Empty Extinguisher 15L H.P.actuation Air freight	1272-020-AIR
	Extinguisher 15L H.P with detect. bottle	1272-03-020

Average filled weight: 40 kg, Height: 805 mm, Width: 380 mm, Depth w bracket ~ 176mm

Piston accumulators, Ø151 triple

Piston accumulators, 12L

Description	Part number
	Extinguisher 12L H.P.actuation
	Extinguisher 12L H.P.actuation Pressure switch
	Extinguisher 12L H.P.actuation with detect. bottle

Average filled weight: 36.5 kg, Height: 485 mm, Width: 552 mm, Depth w bracket ~ 176mm

Piston accumulators, 19.5L

Description	Part number
	Extinguisher 19.5L H.P
	Extinguisher 19.5L H.P.actuation 0°C Pressure switch
	Extinguisher 19.5L H.P.actuation Pressure switch
	Empty Extinguisher 19.5L H.P.actuation Pressure switch for Air freight
	Extinguisher 19.5L HP/PS/Sig. mod.
	Extinguisher 19.5L H.P.actuation 0°C Pressure switch Australian market
	Extinguisher 19.5L H.P with detect. bottle

Average filled weight: 50 kg, Height: 740 mm, Width: 552 mm, Depth w bracket ~ 176mm

Piston accumulators, 22.5L

Description	Part number
	Extinguisher 22.5L M actuation with pressure switch
	Empty Extinguisher 22.5L E/PS/Sig. mod. Metron (Not for trains)
	Extinguisher 22.5L H.P.actuation Pressure switch
	Empty Extinguisher 22.5L H.P.actuation Pressure switch for Air freight
	Extinguisher 22.5L HP/PS/Sig. mod.
	Empty Extinguisher 22.5L H.P.actuation for Air freight

Average filled weight: 58 kg, Height: 805 mm, Width: 552 mm, Depth w bracket ~ 176mm

Piston accumulators, Ø178

Piston accumulator, 6L

Description		Part number
	Piston accumulator 6L HP/PS/Sig. mod. 178 mm	1162-02-030
	Piston accumulator 6L HP/PS/Sig. mod. 178 mm EMPTY	1162-02-030-AIR

Average filled weight: 20.5 kg, Height: 565 mm. Depth w bracket ~ 208mm

Piston accumulator, 11.5L


Description		Part number
	Piston accumulator 11.5L HP/PS/Sig. mod. 178 mm	11122-02-030
	Piston accumulator 11.5L HP/PS/Sig. mod. 178 mm EMPTY	11122-02-030-AIR

Average filled weight: 33 kg, Height: 915 mm. Depth w bracket ~ 208mm


Brackets and clamps

Description		Part number
	Heavy duty clamp Ø151 piston accumulator	5105
	Heavy duty clamp for Ø178 mm piston accumulator	5105-178
	Fixing pin extinguisher	5110

Brackets for single cylinders

Description		Part number
	Assembly fitting/Bracket 3.3 l Suppression cylinder	2400
	Assembly fitting/Bracket 4 l Suppression cylinder	2402
	Assembly fitting/Bracket 6.5 l Suppression cylinder	2403
	Assembly fitting/ Bracket 7.5 l Suppression cylinder	2405
	Bracket for single extinguisher 151 mm 50x40x194mm	2410
	Bracket for single extinguisher 178 mm 50x40x220mm	2413

Brackets for double & triple cylinders

Description		Part number
	Assembly fitting double Suppression cylinder (upper) 50x40x380mm	2440
	Assembly fitting double Suppression cylinder (lower) 50x40x380mm	2441
	Assembly fitting triple Suppression cylinder (upper) 50x40x552mm	2443
	Assembly fitting triple Suppression cylinder (lower) 50x40x552mm	2444
	Plastic spacer for 2441 and 2444	2442

Novec™ extinguisher bottles

Description		Part number
	Extinguisher Novec with 14 bar pressure switch	1008
	Extinguisher Novec with 5 bar and 14 bar pressure switch	1008-02
	Extinguisher Novec with 14 bar pressure switch for Air freight	1008-AIR

Average filled weight: 1.8 kg, Height: 330 mm.

Revision kits for piston accumulator valve

Description		Part number
	Refilling kit piston accumulator 5 times excl. liquid	1929
	Revision kit E single piston accumulator	1930
	Revision kit M single piston accumulator	1931
	Revision kit HP single piston accumulator	1932
	Revision kit E double piston accumulator	1933
	Revision kit M double piston accumulator	1934
	Revision kit HP double piston accumulator	1935


See page 32 for lubricants & thread sealants

Protection boxes

Description		Stainless steel	Part number
	Protection box 6.5 lit - Stainless steel	x	1380-151-065
Height, width, depth (mm): 800, 192, 202			
	Protection box 3.3/4 lit	-	1350
	Protection box 3.3/4 lit - Stainless steel	x	1360
	Protection box 7.5 lit	-	1354
	Protection box 7.5 lit - Stainless steel	x	1364
Height: 564(3.3/4) 810(6.5) 895(7.5), Width: 214, Depth: 200 (mm)			
	Protection box 6.6/8 lit (2x3.3/4)	-	1351
	Protection box 6.6/8 lit (2x3.3/4) - Stainless steel	x	1361
	Protection box 13 lit (2x6.5)	-	1353
	Protection box 13 lit (2x6.5) - Stainless steel	x	1363
	Protection box 15 lit (2x7.5)	-	1355
	Protection box 15 lit (2x7.5) - Stainless steel	x	1365
	Protection box 15 lit (2x7.5) - Stainless steel, extra deep: 240 mm	x	1365-40
Height: 564(6.6/8 lit) 810(13 lit) 895(15 lit), Width: 429, Depth: 200 (mm)			
	Protection box 12 lit (3x4)	-	1357
	Protection box 12 lit (3x4) - Stainless steel	x	1367
	Protection box 19.5 lit (3x6.5)	-	1358
	Protection box 19.5 lit (3x6.5) - Stainless steel	x	1368
	Protection box 22.5 lit (3x7.5)	-	1356
	Protection box 22.5 lit (3x7.5) - Stainless steel	x	1366
Height: 564(12 lit) 810(19.5 lit) 895(22.5 lit), Width: 604, Depth: 200 (mm)			
	Protection box Detector bottle - Stainless steel	x	1370
Height, width, depth (mm): 350, 140, 110			

Distribution system

Nozzles

Description		Part number
	Spray nozzle 0.8 l/min at 30 bar - "F4-4" (incl. pink protection cap)	1502-010
	Spray nozzle 0.8 l/min at 30 bar, UL "F4" (incl. pink protection cap) Stainless steel	1502-012 ^{UL}
	Spray nozzle 1.2 l/min at 30 bar - "F6-4" (incl. orange protection cap)	1503-010
	Spray nozzle 1.2 l/min at 30 bar, UL - "F6-4" (incl. orange protection cap) Stainless steel	1503-012 ^{UL}
	Spray nozzle 3.5 l/min at 30 bar - "F18-4" (incl. purple protection cap)	1506-010
	Spray nozzle 3.5 l/min at 30 bar, UL "F18" (incl. dark blue protection cap) Stainless steel	1506-012 ^{UL}
	Protection cap for 1502-010 nozzles, pink	1505-011
	Protection cap for 1503-010 nozzles, orange	1505-012
	Protection cap for 1506-010 nozzles, purple	1505-013
	Protection cap for 150X nozzles red	1505
	Spray nozzle 1/4" F4 0.8 l/min at 30 bar	1500
	Spray nozzle 1/4" F6 1.2 l/min at 30 bar	1501
	Spray nozzle 1/4" F18 3.5 l/min at 30 bar SBF 128	15010
	Nozzle Protection Cover (Old M4 nozzle)	4503
	Nozzle replacement filter (Old M4 nozzle)	4502
	Plug for cutting ring fittings - used when performing a leak test on the distribution system	1510

Distribution hoses, straight-straight connector

Description		Protection conduit	Stainless steel	Part number
	HP hose 0,32m straight-straight	-	-	4174
	HP hose 0,55m straight-straight	-	-	4101-00
	HP hose 0,55m straight-straight with prot. hose	x	-	4101-00-1
	HP hose 0,75m straight-straight	-	-	4109
	HP hose 1,0m straight-straight	-	-	4126
	HP hose 1,0m straight-straight stainless steel	-	x	4126-20
	HP hose 1,0m straight-straight with prot. conduit	x	-	4178-1
	HP hose 1,2m straight-straight	-	-	41041
	HP hose 1,25m straight-straight	-	-	4118
	HP hose 1,25m straight-straight with prot. conduit	x	-	4118-1
	HP hose 1,4m straight-straight	-	-	4152
	HP hose 1,5m straight-straight	-	-	4108
	HP hose 1,5m straight-straight with prot. conduit	x	-	4108-1
	HP hose 1,5m straight-straight stainless steel	-	x	4108-20
	HP hose 1,6m straight-straight with prot. conduit	x	-	4183-1
	HP hose 2,0m straight-straight	-	-	4111
	HP hose 2,0m straight-straight with prot. conduit	x	-	4111-1
	HP hose 2,5m straight-straight	-	-	4112
	HP hose 2,7m straight-straight	-	-	4156
	HP hose 3,0m straight-straight	-	-	4113
	HP hose 3,5m straight-straight	-	-	4120
	HP hose 4,2m straight-straight	-	-	4128
	HP hose 4,5m straight-straight	-	-	4114
	HP hose 4,5m straight-straight with prot. conduit	x	-	4114-1
	HP hose 4,5m straight-straight stainless steel	-	x	4187
	HP hose 5,0m straight-straight	-	-	4116
	HP hose 5,5m straight-straight	-	-	4115
	HP hose 5,8m straight-straight	-	-	4158
	HP hose 6,1m straight-straight	-	-	4159
	HP hose 6,3m straight-straight stainless steel	-	x	4186
	HP hose 7,3m straight-straight	-	-	4124
	HP hose 7,5m straight-straight	-	-	4164
	HP hose 8,5m straight-straight	-	-	4185
	HP hose 9,7m straight-straight	-	-	4119

Distribution hoses, 90°-90° connector

Description	Protection conduit	Stainless steel	Part number
	HP hose 0,24m 90-90	-	4137
	HP hose 0,7m 90-90	-	4181
	HP hose 1,0m 90-90	-	4177
	HP hose 1,25m 90-90	-	4121
	HP hose 1,9m 90-90	-	4167
	HP hose 2,5m 90-90	-	4154
	HP hose 3,4m 90-90	-	4163
	HP hose 3,5m 90-90 180deg stainless steel	x	4188
	HP hose 5,0m 90-90	-	4157
	HP hose 5,2m 90-90	-	4161
	HP hose 6,0m 90-90	-	4160-99
	HP hose 7,0m 90-90	-	4144

Distribution hoses, straight-90° connector

Description	Protection conduit	Stainless steel	Part number
	HP hose 0,2m straight-90	-	4150
	HP hose 0,32m straight-90 Compact	-	4100
	HP hose 0,32m straight-90 Compact w prot. c	x	4100-1
	HP hose 0,32m straight-90 stainless steel	x	4110
	HP hose 0,4m straight-90	-	4165
	HP hose 0,475m straight-90	-	4100-475
	HP hose 0,5m straight-90	-	4107
	HP hose 0,55m straight-90	-	4101
	HP hose 0,55m straight-90 stainless steel	x	4131
	HP hose 0,65m straight-90 Compact	-	4179
	HP hose 0,7m straight-90	-	4102
	HP hose 0,7m straight-90 with protection conduit	x	4102-1
	HP hose 0,7m straight-90 stainless steel	x	4132
	HP hose 0,72m straight-90	-	4133
	HP hose 0,8m straight-90	-	4103
	HP hose 0,87m straight-90	-	4148
	HP hose 1,0m straight-90	-	4155
	HP hose 1,1m straight-90	-	4168

cont. Distribution hoses, straight-90° connector


Description		Protection conduit	Stainless steel	Part number
	HP hose 1,2m straight-90	-	-	4104
	HP hose 1,2m straight-90 with prot. conduit	x	-	4104-1
	HP hose 1,2m straight-90 stainless steel	-	x	4182
	HP hose 1,3 m straight-90	-	-	4109-130
	HP hose 1,4m straight-90	-	-	4176
	HP hose 1,5m straight-90	-	-	4105
	HP hose 1,5m straight-90 with prot. conduit	x	-	4105-1
	HP hose 1,5m straight-90 Compact	-	-	4153
	HP hose 1,65m straight-90	-	-	4149
	HP hose 1,75m straight-90	-	-	4109-175
	HP hose 1,9m straight-90	-	-	4166
	HP hose 2,0m straight-90	-	-	4106
	HP hose 2,0m straight-90 with prot. conduit	x	-	4106-1
	HP hose 2,1m straight-90 with prot. conduit	x	-	4175-1
	HP hose 2,5m straight-90	-	-	4122
	HP hose 2,5m straight-90 with prot. conduit	x	-	4122-1
	HP hose 2,5m straight-90 stainless steel	-	x	4122-20
	HP hose 2,7m straight-90	-	-	4127
	HP hose 2,7m straight-90 with prot. conduit	x	-	4127-1
	HP hose 3,0m straight-90	-	-	4123
	HP hose 3,0m straight-90 with prot. conduit	x	-	4123-1
	HP hose 3,2m straight-90	-	-	4169
	HP hose 3,2m straight-90 with prot. conduit	x	-	4169-1
	HP hose 3,4m straight-90	-	-	4134
	HP hose 3,5m straight-90	-	-	4173
	HP hose 3,8m straight-90	-	-	4138
	HP hose 4,0m straight-90	-	-	4125
	HP hose 4,0m straight-90 with prot. conduit	x	-	4125-1
	HP hose 4,2m straight-90	-	-	4151
	HP hose 4,5m straight-90	-	-	4145
	HP hose 4,7m straight-90	-	-	4139
	HP hose 4,8m straight-90	-	-	4146
	HP hose 5,0m straight-90	-	-	4140
	HP hose 5,1m straight-90	-	-	4189
	HP hose 5,5m straight-90	-	-	4141



Description		Protection conduit	Stainless steel	Part number
	HP hose 5,5m straight-90 with prot. conduit	x	-	4141-1
	HP hose 5,7m straight-90	-	-	4135
	HP hose 5,8m straight-90	-	-	4162
	HP hose 6,0m straight-90	-	-	4160
	HP hose 6,7m straight-90	-	-	4147
	HP hose 6,7m straight-90 with prot. conduit	x	-	4147-1
	HP hose 7,0m straight-90	-	-	4170
	HP hose 7,0m straight-90 with prot. conduit	x	-	4170-1
	HP hose 7,1m straight-90	-	-	4171
	HP hose 7,2m straight-90	-	-	4172
	HP hose 7,5m straight-90	-	-	4142
	HP hose 7,5m straight-90 with prot. conduit	x	-	4142-1
	HP hose 8,0m straight-90	-	-	4129
	HP hose 8,0m straight-90 with prot. conduit	x	-	4129-1
	HP hose 8,35m straight-90	-	-	4136
	HP hose 8,5m straight-90	-	-	4143
	HP hose 10,0m straight-90	-	-	4184

Pipe




Description		Stainless steel	Part number
	Stainless steel piping 8 x 1150 mm	x	4008-115

Hose/ Hose-Pipe connectors

Description		Stainless steel	Part number
	Nipple 1/4" UxUF Stainless steel	x	4607
	Bulk head connector Hydraulic hose 1/4" UxUF Stainless steel	x	4385
	Bulk head connector Hydraulic hose 1/4" UxUF		4305
	Nozzle Connector 1/4" MxM		4304
	Connector nipple 1/4" outer-1/8" inner		4313
	Sleeve 1/4" Stainless steel	x	4386
	Sleeve 1/4"		4306
	Sleeve 1/8"		4306-18
	Sleeve 1/4"-1/8" Stainless steel	x	4396
	Sleeve 1/4"-1/8"		4316
	Sleeve 1/4"-3/8"		4321
	Straight connector 8x1/4" Stainless steel	x	4466
	Straight connector 8x1/4"		4400

Description		Stainless steel	Part number
	Nozzle connector 8x1/4" F Stainless steel	x	4469
	Nozzle connector 8x1/4" F		4404
T-connectors:			
	T-connector 1/4" UFXUFxUF		4301
	T-connector 1/4" IRxIRxIR		4302
	T-connector 1/4" UFXUFxIR		4303
	T-connector 1/4" UFXIRxUF		4303-010
Elbow connectors:			
	Elbow nipple 45 degrees 1/4" UFXIR		4308
	Elbow nipple 90 degrees 1/4" UFXIR		4309
Flush connectors:			
	Flush connector to 8L compression fitting swivel nut		4325-010
	Flush connector with 1/4" BSP ext. straight th. and sealing		4325-011
	Flush connector M16x2 to 1/4" BSPT interior semi fabr.		4325-012

Pipe connectors 8 mm

Description		Stainless steel	Part number
	T-connector 8x8x8 Stainless steel	x	4467
	Equal Tee 8x8x8		4401
	Straight connector 8x8 Stainless steel	x	4465
	Straight connector 8x8		4402
	T-connector 8x1/4"x8 Stainless steel	x	4468
	Stud Branch Tee 8x1/4"x8 tapered		4403
	Equal 90 degrees Elbow 8x8 Stainless steel	x	4452
	Equal 90 degrees Elbow 8x8		4409
	Equal cross 8x8x8x8		4408
Bulkhead connectors, pipe:			
	Bulkhead connection piping 8x8		4405
	Bulkhead 90 degrees elbow 8x8		4406
Cutting ring and nut:			
	8 mm cutting ring		4490
	Nut for 8 mm cutting ring		4491

Washers & plugs

Description		Stainless steel	Part number
	Stainless steel rubber washer 1/8"	x	5605
	Steel rubber washer 1/8"		5005
	Stainless steel rubber washer 1/4"	x	5606
	Plane washer 6,4x18x1,6 FZB		5008-06-18
	Plane washer 8,4x24x2,0 FZB		5008-08-24
	Copper washer (f. pressure switch)		5009
	Aluminium washer 6-10 X 1		5011
	Washer 5,3/10/1 Stainless steel	x	5015
	Washer 4,3/9/0,8 Stainless steel	x	5015-430908-A2
	Washer 8,4, Stainless steel	x	5018
	Plug 1/8"		5049
	Plug 1/4"		5050
	Plug 1/4" for the filling nipple with temp fuse hex	x	5050-035
	Filling screw with groove SS	x	2132
	Filling screw with groove SS and temp fuse hex	x	2132-035

Schrader adapters

Description		Part number
	Schrader 1/8" IF brass complete with cap	4415-000
	Schrader valve opener for 4906-010	4415-021
	Schrader valve gasket for 4906-010 Black	4415-022
	Schrader valve gasket for 4906-010 Green	4415-023
	Schrader valve tool for 4906-010	4415-025
	Spare part valve tool for 4906-010	4415-0251
	Schrader valve gasket 10 pcs for 4906-010	4415-122

Detection system

Detector bottles

Description		Part number
	Hydro-pneum. detector bottle 31 bar with 5 and 14 bar pressure switch T-fitting	1654
	Hydro-pneum. detector bottle 24 bar with 5 and 14 bar pressure switch T-fitting	1654-00-24
	Hydro-pneum. detector bottle (no gas) with 5 and 14 bar pressure switch T-fitting	1654-AIR
	Hydro-pneum. detector bottle 31 bar with 5 and 14 bar pressure switch L-fitting	1655
	Hydro-pneum. detector bottle 24 bar with 5 and 14 bar pressure switch L-fitting	1655-00-24
	Hydro-pneum. detector bottle (no gas) with 5 and 14 bar pressure switch L-fitting	1655-AIR
	Hydro-pneum. detector bottle 31 bar with 14 bar pressure switch T-fitting	1656
	Hydro-pneum. detector bottle 24 bar with 14 bar pressure switch T-fitting	1656-00-24
	Hydro-pneum. detector bottle 24 bar with 14 bar pressure switch T-fitting UL	1656-08-24 ^{UL}
	Hydro-pneumatic detector bottle (no gas) with 14 bar pressure switch T-fitting	1656-AIR
	Hydro-pneum. detector bottle 31 bar with 14 bar pressure switch L-fitting	1657
	Hydro-pneum. detector bottle 24 bar with 14 bar pressure switch L-fitting	1657-00-24
	Hydro-pneum. detector bottle 24 bar with 14 bar pressure switch L-fitting UL	1657-08-24 ^{UL}
	Hydro-pneum. detector bottle (no gas) with 14 bar pressure switch L-fitting	1657-AIR
	Detector gas cylinder 31bar (no detector fluid) with 14 bar pressure switch L-fitting	1740
	Detector gas cylinder 31bar (no detector fluid) with 14 bar pressure switch T-fitting	1740-06

Average filled weight: 1.4 kg, Height: 330 mm.


Brackets and clamps for Detector bottle

Description		Part number
	Brace/clamp 73/20 W4 - for installation of detector bottle	5373-20
	Bracket detector cylinder kit	5109

Detector tube, protection coil & protection conduit

Description		Part number
	Fogmaker hydro-pneumatic detector tube (3,8/6) translucid / meter	40380
	Gas detector tube Novec™ (Red)	4024
	6 mm protective coil 1,0m /unit	4291
	6 mm protective coil 2,5m /unit	4292
	6 mm protective coil 4,5m /unit	4294
	6 mm protective coil 5m /unit	4295
	6 mm protective coil 6m /unit	4296
	6 mm protective coil 7m /unit	4297
	6 mm protective coil 8m /unit	4298
	Protection conduit Fogmaker 8.4/11.7mm orange [per meter]	4713
	Protection conduit Fogmaker 8.4/11.7mm red [per meter]	47132
	Protection conduit Fogmaker 10/13.4mm orange [per meter]	4715
	Protection conduit Fogmaker 10/13,4mm red [per meter]	47152

6 mm couplings (for detection system)

Description		Part number
	Bulk head connector detector tube 20 mm	4248
	Support sleeve for detection tube	4249
	Detection tube coupling R6-1/8	4250
	Detection tube T-coupling T6-1/8-6	4253
	Detection tube coupling SR L6-1/8	4254
	Coupling L6-M5	4254-M5
	Detection tube straight coupling 6mm - 6mm	4255
	Detection tube T-coupling	4256
	End plug, detection tube	4258
	End plug, detection tube compact	4258-02
	End plug with clamp, support sleeve and screw	4258-05
	End plug compact with clamp, support sleeve and screw	4258-06
	Cutting ring 1/8"	4259

Installation material




Nuts & bolts

Description		Part number
	Locknut M6	5222
	Screw, Self tapping M6x16	5246

Steel-rubber clamps

Description		Stainless steel	Part number
	Brace/clamps 6/15 W4	x	5306
	Brace/clamps 8/15 W4 - for installation of pipes and detector tube	x	5308
	Brace/clamps 8/20 W4	x	5308-20
	Brace/clamps 10/15 W4	x	5310
	Brace/clamps 12/15 W4 - for installation of end plug	x	5312
	Brace/clamps 14/15 W4 - for installation of distribution hoses	x	5314
	Brace/clamps 14/20 W4	x	5314-20
	Brace/clamps 18/15 W4 - for installation of fittings/connectors	x	5318
	Brace/clamps 18/20 W4	x	5318-20
	Brace/clamps 20/15 W4	x	5320
	Brace/clamps 21/12 W1	x	5321
	Brace/clamps 22/15 W4	x	5322
	Brace/clamps 22/20 W4	x	5322-20
	Brace/clamps 30/15 W4	x	5330
	Brace/clamps 34/20 W4	x	5334-20

Brackets & cable ties

Description		Part number
	Straight bracket Stainless Steel 135 mm	5384
	L-bracket Stainless Steel 50 x 50	5385
	L-bracket Stainless Steel 50 x 100	5386
	L-bracket Stainless Steel 50 x 150	5387
	L-bracket kit Stainless steel (1x5385, 3x5386, 1x5387)	5397
Cable ties		
	Cable tie L=100 w=2,5 black	8931
	Cable tie L=200 w=4,6 black	8935
	Cable tie L=380 w=7,6 black	8938
	Cable tie L=370 w=12,5 black	8939



Alarm units

Alarm kits and brackets

Description	Part number	
	Alarm kit incl. button (mounted in dashboard) 24V	1747-020-00
	Alarm kit incl. button (mounted in dashboard) 12V	1747-020-12
	Alarm panel kit for 1 pressure switch	1746-071
	Alarm panel kit for 2-3 pressure switches	1746-072
	Mounting bracket for Alarm panel for 1-3 press. switches (upwards mounting)	1746-055
	Mounting bracket for Alarm panel for 1-3 press. switches (side mounting)	1746-065

Separate alarm units

Description	Part number	
	Pushbutton red/yellow light 12/24 V M19, Ø22mm	6970-05
	SWF rocker switch with test button, 24V 45x22mm cut-out	6970
	Low pressure lamp 24V for dashboard red lens	1770
	Low pressure lamp 24V for dashboard yellow lens	1770-01
	Alarm panel for 1-3 press. switches, 12/24 V	1746-050

Description		Part number
	Buzzer 12/24V 95 dB	1750
	Buzzer 12/24V 85 dB Compact (for 1747-020-00 Alarm kit)	1750-05
	Alarm siren 12-24V	1751
	Optical alarm strobe red 12-24VDC/2W with mount	1760
	Relay change over 24V 22A/10A	1795
	Relay socket multi-purpose	1796
	Micro switch kit	6009-020
	Safety screw 1st generation valve	5252-01
	Signal module kit incl safety wire and screws with magnet	6009-030
	Safety wire and screws with magnet	5902-020-M
	Safety wire and screws NO magnet	5902-020
	Installation cable 4-wire 0,75 mm ² /m	6810
	Installation cable 2-wire 0,75 mm ² /m	6811
	Installation cable 7-wire 0,75 mm ² /m	6812
	Fuse holder	6910
	Fuse 5A	6912
	Connector 2 tabs complete with contacts and sealing	69831
	Connector 2 receptacles complete with contacts and sealing	69841


See also Complete kit for AMP Superséal (Part no. 1805-030) on page 30

Handles & Actuators/Punches

Mechanical activation handles (for mechanical valve)

Description		Part number
	0,340 m activation wires incl. security stop	1309-00340-00
	0,550 m activation wires incl. security stop	1309-00550-00
	0,750 m activation wires incl. security stop	1309-00750-00
	0,950 m activation wires incl. security stop	1309-00950-00
	2,270 m activation wires incl. security stop	1309-02270-00
	2,5m actuation wire incl. safety interlock.	1310
	6m actuation wire incl. safety interlock	1311
	10m actuation wire incl. safety interlock.	1312
	Handle kit for wire without clamps, no wire	1313-01
	Wiresplit for 2 actuation wires	1319
	Safety interlock large for wire handle	1321
	Protection for wire handle -heavy duty	1322

Electric activation (for electrically actuated valve or elec. punch)

Description		Part number
	Red push button with cover	6992
	Kit Push button Fire for electric actuator	6999


Manual punches connected to hydropneumatic detector tube

Description		Part number
	Manual actuator detector tube Heavy duty incl cover	1315-030
	Manual actuator detector tube (T-coupling)	1316
	Manual actuator detector tube (L-coupling)	1316-L
	Holder (short) Mechanical actuator detector tube	1317-06
	Holder (long) Mechanical actuator detector tube	1317-07
	Holder (angle) Manual punch detector tube	1317-08
	Protection for 1316	1322-05



Electrical punches connected to hydropneumatic detector tube


Description		Part number
	Electrical actuator detector tube	1318
	Electrical actuator detector tube (For trains)	1318-T
	Electrical actuator detector tube, Metron	1318-05-M
	Repair kit, elec. actuator detector tube, Metron	1318-05-M-R
	Electrical actuator detector tube Metron (For trains)	1318-05-MT

Solenoid valve for semi-automatic function connected to detector tube

Description		Part number
	Solenoid valve kit - 1/8" NO 24VDC	4926


Tools

Description		Part number
	Bottle with pump (Gloria 1L) and modified coupling, for prefilling detector tube	1012-01
	Filling tool for fire suppression cylinder G 1/4"	1800
	Filling tool for fire suppression cylinder G 1/4" Long model	1800_L
	Hook knife big (Protection conduit)	1804-06
	Complete kit for AMP Superseal	1805-030
	Cutting tool Super Ego 35 mm - Stainless steel piping	1807
	Pipe bending tool R8	1808
	Cutting tool - Detector tube	1809
	Filling station complete (Kränzle) (Incl 1811-05, 1800-L & 7910)	1810-05
	Filling pump with hose kit (Kränzle)	1811-05
	Tool for nozzle 1/4"	1819

Description		Part number
	Dismantling tool for cylinder cover	1820
	Protection tool o-ring high pressure piston valve 6092	1821
	Long sleeve 1/2" for pressure relief valve - 6092-xx service	1822-17-L
	Tool for refilling of the detector bottle	1970
	Tool universal for gas filling of piston accumulator and detector bottle	1975
	Tool for flushing of distribution system (fits to filling pump)	1977-010
	Gas filling kit for piston accumulator and detector bottle	7910

Chemicals

Extinguishant & detector liquid

Description		Part number
	Extinguishant -35°C 25 liters	1891
	Extinguishant -35°C 200 liters	1831-200
	Extinguishant -35°C 1000 liters	1831-1000
	Extinguishant 0°C 25 litres	1890
	Detector liquid red 25 liter	7030-25
	Detector liquid red 1 liter	7031
	Detector liquid red 5 liter	7032
	Detector liquid red 0.25 liter	7033
	Detector liquid red 0.15 liter	7034
	Extinguishant Concentrate 0°C 0.75 liter	7100-01
	Extinguishant Concentrate 0°C 5 liter	7100-05

Lubricants & thread sealants

Description		Part number
	Silikon oil Dow corning 200 1 kg	7900-1000
	Loctite 577, 50 ml	7904
	Molykote 111 C 100g	7907
	Molykote P40	7913

See also Refilling kit (Part no. 1929) on page 9.

Technical Documentation

Material safety data sheets, MSDS

Description	Part number
	MSDS detector liquid -30°C SWE
	80041-001-001
	MSDS detector liquid -30°C ENG
	80041-001-002
	MSDS detector liquid -30°C DEU
	80041-001-003
	MSDS detector liquid -30°C ITA
	80041-001-005
	MSDS detector liquid -30°C FRA
	80041-001-006
	MSDS detector liquid -30°C ESP
	80041-001-007
	MSDS detector liquid -30°C POL
	80041-001-008
	MSDS detector liquid -30°C FIN
	80041-001-009
	MSDS detector bottle -30°C SWE
	80042-001
	MSDS detector bottle -30°C ENG
	80042-002
	MSDS detector bottle -30°C DEU
	MSDS detector bottle -30°C ITA
	80042-005
	MSDS detector bottle -30°C ESP
	80042-007
	MSDS extinguishant -35°C ENG
	80053-001
	MSDS extinguishant -35°C SWE
	80053-002
	MSDS extinguishant -35°C DEU
	80053-003
	MSDS extinguishant -35°C ITA
	80053-005
	MSDS extinguishant -35°C FRA
	80053-006
	MSDS extinguishant -35°C ESP
	80053-007
	MSDS extinguishant -35°C POL
	80053-008
	MSDS Piston accumulator -35°C SWE
	80054-001
	MSDS Piston accumulator -35°C ENG
	80054-002
	MSDS Piston accumulator -35°C DEU
	MSDS Piston accumulator -35°C ITA
	80054-005
	MSDS Piston accumulator -35°C ESP
	80054-007

Installation manual

Description	Part number	
 INSTALLATION MANUAL Instructions for installation of fogmaker fire suppression system	Installation manual SWE	8010-001
	Installation manual ENG	8010-002
	Installation manual DEU	8010-003
	Installation manual ESP	8010-007
	Installation manual POL coming soon...	8010-008
	Installation manual acc. to SPCR183 ENG	8024-002


Service manual

Description	Part number	
 SERVICE MANUAL Instructions for service, control and repair of fogmaker fire suppression system	Service manual SWE	8011-001
	Service manual ENG	8011-002
	Service manual DEU	8011-003
	Service manual ESP	8011-007



User manuals

Description	Part number	
	User Manual Bus SWE	8012-001
	User Manual Bus ENG	8012-002
	User Manual Bus DEU	8012-003
	User Manual Bus NLD	8012-004
	User Manual Bus ITA	8012-005
	User Manual Bus FRA	8012-006
	User Manual Bus ESP	8012-007
	User Manual Bus FIN	8012-009
	User Manual Bus TUR	8012-011
	User Manual Contract Machine SWE	8013-001
	User Manual Contract Machine ENG	8013-002
	User Manual Contract Machine DEU	8013-003
	User Manual Contract Machine NLD	8013-004
	User Manual Contract Machine ITA	8013-005
	User Manual Contract Machine FRA	8013-006
	User Manual Contract Machine ESP	8013-007
	User Manual Contract Machine NOR	8013-009
	User Manual Contract Machine FIN	8013-010
	User Manual Marine SWE	8016-001
	User Manual Marine ENG	8016-002
	User Manual Trucks SWE	8017-001
	User Manual Trucks ENG	8017-002

Wiring diagrams

Description	Part number	
	Wiring diagram 1747-020/6722-020	8082-20
	Wiring diagram 1747-020/6722-020 Extra relay	8082-21

Other instructions

Description	Part number	
	Instruction Pressurise detector tube SWE_ENG	8025-001
	Instruction Fyllpump (Art.nr. 1811-05) SWE_ENG	8026
	Instruction Novec 1008-AIR pressurizing ENG	8041-002
	Instruction for Solenoid valve, 4926	8081-001
	Instruction for Solenoid valve, 4926-R	8081-002
	Instruction Signal module SWE ENG DEU ESP	8089-001
	Instruction manual activator 1316 ENG-SWE	8094
	Instruction "installing the alarmpanel 1746-050" ENG-SWE	8096-050-01
	Instruction assembly single PA into mounting double brackets ENG	8098
	Instruction manual activator 1315-025/-030 ENG-SWE	8099

Labels & plates

Labels for piston accumulator/detector bottle/protection box

Description		Part number
	Label Piston accumulator Serial no. ENG <i>State serial no when ordering!</i>	8100
	Label for 8100 Year marker Next Annual control	8105
	Label for 8100 Marker freeze point extinguishant	8106
	Label Piston accumulator Next 5-year-service ENG - SWE - DEU - ESP	8101
	Label Piston accumulator/Protection box Warning ENG	8104
	Label Piston accumulator/Protection box "Warning contains gas" ENG-DEU-ESP-FRA-NLD-SWE-FIN	8207
	Label Piston accumulator "CE-mark & pressure test" ENG. <i>State serial no when ordering!</i>	8190
	Label f valve Gen. 1 "Safety screw" ENG	8107
	Label f valve Gen. 1 "Safety screw" TUR	8107-011
	Label f valve Gen. 1 "Safety screw" FRA	8217
	Label f valve Gen. 1 "Safety screw" ESP	8423
	Label for connection hose on double/triple extinguishers	8223
	Label for Hydropneum. Detector bottle ENG	8120-01
	Label for Hydropneum. Detector bottle SWE	8120-05
	Label for Hydropneum. Detector bottle ESP	8120-07
	Label Detector gas cylinder ENG	8435
	Label Detector gas cylinder FRA	8213
	Label Detector tube Pictogram	8220
	Label Serial number detector cylinder <i>State serial no when ordering!</i>	8191

Labels for Novec

Description	Part number	
	Label "Extinguisher Novec" SWE	8108-01
	Label "Extinguisher Novec" ENG	8108-02
	Label "Extinguisher Novec" ESP	8108-07
	Label "Extinguisher Novec" ROU	8108-08
230 NOVEC 1230 NOV FIRE SUPPRESSION SYSTEM FIRE SUPPRESSION SYSTEM	Label "Novec 1230 Fire suppression system" ENG	8112



Labels for Actuators and more...see also Plates

Description	Part number	
	Label "Annual control" SWE	8111-001
	Label "Annual control" ENG	8111-002
	Label "Annual control" DEU	8111-003
	Label "Annual control" FRA	8111-006
	Label "Annual control" ESP	8111-007
	Label "Annual control" NOR	8111-010
	Label Actuator SWE	8201-01
	Label Actuator ENG	8201-02
	Label "Fire alarm" SWE	8205-01
	Label "Fire alarm" ENG	8205-02
	Label "Fire alarm" DEU	8205-03
	Label "Fire alarm" FRA	8205-06
	Label "Fire alarm" ESP	8205-07

Labels for Driver's area, see also Plates

Description		Part number
Driver information Fogmaker Fire Suppression system This vehicle is equipped with a fully automatic fire suppression system to suppress and protect against fire in the engine compartment. Function: The pressurized detector tube will burst when fire occurs and activate the suppressor system automatically. Daily monitoring of system is required if no pressure switch mounted. Check main valve pressure on suppressor bottle: pressure is OK at 90 bar Eng when +20°C. Detector bottle pressure is OK at 20 bar when +20°C. Pressure drops below 10 bar the system will alarm. Pressure below 5 bar will release the suppressor. The system's safety screw must be inserted into valve prior to all work on fogmaker system (except service engine). Remove safety screw after work is completed! FOGMAKER Fogmaker International AB, Box 8005, SE-300 08 Västerås Tel: +46 (0) 77 22 10 10, Fax: +46 (0) 77 22 10 11 info@fogmaker.com, www.fogmaker.com 8421	Label "Drivers info" Auto SWE	8421
	Label "Drivers info" Auto FIN	8421-009
	Label "Drivers info" Auto ENG	8432
	Label "Drivers info" Auto NLD	8433
FÖRÄRINFORMATION FOGMAKER BRANDSKYDDSSYSTEM Fordonet är utrustat med en släckanläggning som skyddar motorrummet vid brand. Vid brand: - Stänga motorn och bryt huvudströmmen. - Unds släckanläggningen genom att dra i något av aktiveringshandtagen. Daglig tillsyn av släckanläggning: Kontrollera motornivåtrycket i släckmedelsbehållaren (normalt 100 bar vid 20°C). Vid service och reparationsarbete skall säkerhetsniven på släckmedelsbehållaren monteras. ÖBS! Demontera säkerhetsniven efter avslutad service. FOGMAKER INTERNATIONAL AB Fogmaker International AB, Box 8005, SE-300 08 Västerås Tel: +46 (0) 77 22 10 10, Fax: +46 (0) 77 22 10 11 info@fogmaker.com, www.fogmaker.com 8436	Label "Drivers info" Mec SWE	8436
	Label "Drivers info" Mec ESP	8436-07
FOGMAKER INTERNATIONAL AB This vehicle is equipped with an automatic fire suppression system in the engine compartment IN CASE OF FIRE: 1. Switch off engine and ventilation 2. Evacuate vehicle 3. Switch off main power 4. If needed, use hand extinguisher www.fogmaker.com 8430	Label "In case of fire" Auto SWE	8422
	Label "In case of fire" Auto ENG	8430
	Label "In case of fire" Auto DEU	8430-01
	Label "In case of fire" Auto FRA	8430-06
	Label "In case of fire" Auto ESP	8430-007
	Label "In case of fire" Auto ROU	8422-08
	Label "In case of fire" Auto FIN	8422-009
	Label "In case of fire" Auto NOR	8422-010
	Label "In case of fire" Auto TUR	8430-011
FOGMAKER INTERNATIONAL AB Detta fordon är utrustat med halvautomatiskt brandskyddssystem i motorrummet. VID BRAND: 1. Flytta fordonet ifrån brandfarlig miljö om möjligt 2. Stäng av motorn 3. Bryt huvudströmmen 4. Vid behov använd handbrandsläckare www.fogmaker.com 8426	Label "In case of fire" Semi-auto SWE	8426
FOGMAKER INTERNATIONAL AB This vehicle is equipped with a manually activated fire suppression system in the engine compartment IN CASE OF FIRE: 1. Switch off engine and ventilation 2. Turn off main power 3. Deploy the Fogmaker system 4. If needed, use hand extinguisher www.fogmaker.com 8429	Label "In case of fire" Mec SWE	8428
	Label "In case of fire" Mec ENG	8429
	Label "In case of fire" Mec DEU	8429-03
	Label "In case of fire" Mec ESP	8424
	Label "In case of fire" Mec FIN	8428-009

Plates

Description	Part number	
	Plate "Activation of engine sprinkler system" SWE	8221
	Plate "Activation of engine sprinkler system" ENG	8221-01
	Plate "Activation of engine sprinkler system" NOR	8221-010
	Plate "Activation of fire suppression system" SWE	8300
	Plate "Activation of fire suppression system" ENG	8302
	Plate "Activation of fire suppression system" DEU	8304
	Plate "Activation of fire suppression system" FIN	8300-009
	Plate "Activation of fire suppression system" NOR	8300-010
	Plate "In case of fire" Mec SWE	8301
	Plate "In case of fire" Mec ENG	8303
	Plate "In case of fire" Mec DEU	8305
	Plate "In case of fire" Mec NOR	8301-010
	Plate "In case of fire" Auto SWE	8422-01-AI
	Plate "In case of fire" Auto SWE	8306
	Plate "In case of fire" Auto ENG	8307
	Plate "In case of fire" Auto DEU	8308
	Plate "In case of fire" Auto NOR	8306-010

Fogmaker stickers

Description	Part number	
	Sticker "The engine comp. is protected" ENG	8203
	Sticker "The engine comp. is protected" SWE	8204
	Sticker "The engine comp. is protected" ESP	8204-07
	Sticker "This engine room is prot." Dome decal SWE	8470-001
	Sticker "This engine room is prot." Dome decal ENG	8470-002
	Sticker "This engine room is prot." Dome decal DEU	8470-003
	Sticker "This engine room is prot." Dome decal ESP	8470-007
	Sticker "This engine room is prot." Dome decal FIN	8470-009
	Sticker "This engine room is prot." Dome decal NOR	8470-010
	Sticker "Fogmaker" SWE	8471-001
	Sticker "Fogmaker" ENG	8471-002
	Sticker "Fogmaker" DEU	8471-003
	Sticker "Fogmaker" ESP	8471-007

Merchandise

Brochures

Description	Part number
 FOGMAKER Effektivt brandskydd med vattandimma under högtryck i motorrum	Brochure bus SWE
	Brochure bus ENG
	Brochure bus DEU
	Brochure bus ESP
 FOGMAKER Effektivt brandskydd med vattandimma under högtryck i motorrum	Brochure Machine SWE
	Brochure Machine ENG
	Brochure Machine DEU
	Brochure Machine ESP
 FOGMAKER Fire suppression with high pressure water mist Pure performance since 1905	Brochure Material handling ENG
 FOGMAKER TRIPLE ACTION[®]	Brochure Mining machines ENG
	Brochure Mining machines ESP

Fogmaker collection

Description	Part number
 Fogmaker Haglöfs fleece jacket "Solo" S, M, L, XL, XXL Embroidered 8 cm logo on chest	9907
 Fogmaker T-Shirt "Ace" Black w orange seams Small 8 cm logo print on chest	9901
 Fogmaker printed Sweatshirt S, M, L, XL, XXL Small 8 cm logo print on chest and large logo on back	9908
 Fogmaker Knit cap, one-size	9909
 Fogmaker Baseball cap, one-size	9910
 Fogmaker Storm umbrella, XL black Small logo print on one panel	9904
 Fogmaker USB Stick Piston accumulator 16G USB 3.0	9903
 Pen, braided metal	9906
 Fogmaker ice scraper, plastic w sharp edges 120x100mm	9911

Index

A

Alarm kits 26

B

Brackets 8, 25

Brochures 41

Buttons 26

C

Cable ties 25

Chemicals 32

Clamps, detector bottle 21

Connectors 16

Couplings 23

Cylinder brackets 8

D

Detector bottles 21

Detector liquid 32

Detector tube 22

Distribution hoses 12

E

Electrical activation 28

Extinguishant 32

I

Installation manual 33

Instructions 36

L

Labels 37

Lubricants 32

M

Material Safety Data Sheet 33

Mechanical activation 28

N

Novec™ bottles 9

Nozzles 11

Nuts & Bolts 24

P

Pipe 16

Piston accumulators Ø151 1

Piston accumulators Ø178 7

Plates 40

Protection boxes 10

Protection coil 22

Protection conduit 22

Punches 29

R

Revision kits 9

S

Schrader adapters 20

Sealants 32

Service manual 34

Signal module 27

Solenoid valve 29

Steel-rubber clamps 24

T

Tools 30

U

User manuals 35

V

Washers and plugs 19

Wiring diagrams 36

Fogmaker International AB

Postal address:
PO Box 8005
SE-350 08 Växjö, Sweden

Delivery address:
Sandvägen 4
SE-352 45 Växjö, Sweden

Phone: +46 470-77 22 00
Fax: +46 470-77 22 10
info@fogmaker.com

© Copyright Fogmaker International AB 2016
Reproduction and copying prohibited